

Wall Fixing Methods:

For fully concealed effect, please use method number three:

1. Not concealed

2. Partially concealed

3. Fully concealed

No.8 screws are required for the fully concealed option.

